SMARTFrame XG MRI-Guided Trajectory Frame, INSTRUCTIONS FOR USE

ED-201719 Rev 03

CE 0344

Table of Contents

I. **Intended Use**
II. **Device Description**
III. **General Warnings and Precautions**
IV. **Use Instructions**
A. **Preparation**
B. **Mounting the Skull Mount Base and SMARTFrame XG Tower**
C. **Mounting the Scalp Mount Base**
D. **Attachment of the Thumb Wheel Extension Set**
E. **Set Trajectory**
F. **Exchanging the Cannula and Device Guides and Inserting Instruments**
G. **Navigational Accuracy**
H. **Procedures Utilizing the CleanPoint Neuro Stylet and Peel-Away Sheath**
I. **Direct Insertion Procedures**
J. **System Removal**
K. **Storage and Technical Specifications**

I. Intended Use

The CleanPoint System is intended to provide stereotactic guidance for the placement and operation of instruments or devices during planning and operation of neurological procedures within the MRI environment and in conjunction with MR imaging. The CleanPoint System is intended as an integral part of procedures that have traditionally used stereotactic methodology. These procedures include biopsies, catheter and electrode insertion. The System is intended for use only with 3.0 Tesla MR scanners.

Warning: The CleanPoint Neuro CleanPoint System ALONE should not be used to guide a deep brain stimulation (DBS) electrode into a specific brain target such as the subthalamic nucleus. Final placement of DBS electrodes requires physiological recordings to confirm that they are located in the correct brain target and functioning as intended. The CleanPoint Neuro CleanPoint System is not designed or intended to be used for physiological recording of brain activity. The safety and effectiveness of using the CleanPoint Neuro CleanPoint System ALONE for final placement of DBS electrodes has not been studied.

Warning: This device is intended for single use only. Contents of unopened, undamaged package are sterile. Do not re-sterilize.

Note: For a complete procedure description, refer to CleanPoint System User's Guide.

II. Device Description

Package Contents (one of the following):

NGS-SF-02-11-E	**SMARTFrame XG MRI-Guided Trajectory Frame - Europe**, Stereotactic Frame, Skull Mount Base, Centering Ring, Dock, 5 Fr Device Lock, Large Device Lock, Screwdriver, Roll Lock Screw w/ washer, Rescue Screw (3)	**NGS-SF-02-11-5-E**	**SMARTFrame XG MRI-Guided Trajectory Frame, 5 Fr - Europe** Stereotactic Frame, Centering Ring, Dock, 5 Fr Device Lock, Large Device Lock, Screwdriver, Roll Lock Screw w/ washer

Associated Devices:

NGS-TE-01	**SMARTFrame Thumb Wheel Extension Set.** Light Hand Controller	**NGS-PD-02-L-E**	**MR Neuro Procedure Drape Tapered - Long** MR Neuro Procedure Drape, Marker Pen
NGS-AK-01-11-4-E	**SMARTFrame Accessory Kit - Europe** 4 Fr Stylet, 4 Fr ID Peel-Away Sheath (2), Ruler, Depth Stop (2)	**NGS-PD-03-L-E**	**MR Neuro Procedure Drape Tapered w/ Extension - Long** MR Neuro Procedure Drape Tapered w/ Extension, Marker Pen
NGS-AK-01-11-5-E	**SMARTFrame Accessory Kit, 5 Fr - Europe** 5 Fr Stylet, 5 Fr ID Peel-Away Sheath (2), Ruler, Depth Stop (2)	**NGS-PD-04-E**	**MR Neuro Scanner Bone Drape w/ Extension** MR Neuro Scanner Bone Drape w/ Extension
NGS-AK-01-11-7-E	**SMARTFrame Accessory Kit, 7 Fr - Europe** 7 Fr Stylet, 7 Fr ID Peel-Away Sheath (2), Ruler, Depth Stop (2)	**NGS-PD-05-E**	**MR Neuro Patient Drape** MR Neuro Patient Drape, Marker Pen, Cable Cover
NGS-SG-01-11	**SMARTGrid MR Planning Grid** Marking Grid and Marker Block	**NGS-XG-01-E**	**SMARTFrame XG Exchangeable Device Guides** Device Guide, 3.4 mm, Device Guide, 5.0 mm
NGS-SM-01-E	**Scalp Mount Base - Europe** Scalp Mount Base and centering tool, Rescue Screw (3)	**NGS-XG-03-E**	**SMARTFrame XG Exchangeable Device Guide, 2.5 mm** 2.5 mm Device Guide
NGS-XG-02-E	**SMARTFrame XG Exchangeable Device Guide, 4.5 mm** 4.5 mm Device Guide	**NGS-TC-01**	**SMARTFrame XG Targeting Cannula** Targeting Cannula
NGS-GT-01	**SMARTFrame Guide Tubes** 15 GA Guide Tube, 18 GA Guide Tube and 16GA Guide Tube		

NOTE: If using devices other than those provided by CleanPoint Neuro, verify the device's fit in the Guide Tube, Device Guide, or Drill Guide, and follow the manufacturer's recommendations regarding MRI Compatibility prior to use.

The SMARTFrame XG (Exchangeable Guide) Tower is designed to be used with the Scalp Mount Base or the standard SMARTFrame Base, both of which are completely made of plastic, except for the bone screws and stand-off pins. The Tower (**see Figure 1**) attaches to the Base. The Tower, also completely made of plastic, is designed to provide multi-directional orientation adjustments to the Targeting Cannula, which is housed in the center of the Tower. The Targeting Cannula has a distinctive fiducial component and a proximal fluid filled column that are both MRI visible. The Targeting Cannula also has a central lumen through which a Peel-Away Sheath and Stylet or other suitable devices can be placed and oriented. The Tower, when attached to the Scalp Mount Base, provides adjustments in the roll, pitch, X, and Y directions by means of three adjustment wheels. The XG Tower has a Cap that can be removed so that the Targeting Cannula can be replaced with SMARTFrame XG Exchangeable Device Guides that accept different sized instruments after the trajectory target is obtained and locked. **See Figure 2.**

In non-clinical testing, the CleanPoint System produced a temperature rise of less than 1°C at a maximum whole body averaged specific absorption rate (SAR) of 2.0 W/kg for 15 minutes of MR scanning in a 1.5T GE Signa MR scanner with Excite ver. 11.0 software and in a 3T Siemens Magnetom Tro MR scanner with vc VB17 software.

IV. Use Instructions

A. Preparation

The SMARTFrame XG is packaged with a double sterile barrier: a tray with a sealed Tyvek lid is placed inside a sealed mylar/Tyvek pouch. Each SMARTFrame XG package contains the devices necessary for a uni-lateral procedure. A bi-lateral procedure will require opening two (2) SMARTFrame packages.

Warning: Do not use the SMARTFrame XG or any of the components if the packaging is damaged.

1. The Patient's head shall be prepared just prior to surgery by either shaving the entire head and applying ixicaine tape or by shaving the area that will be covered with the Marking Grids and the area around them.
2. The patient's head is positioned outside the scanner at the head end of the scanner.
3. The patient is prepped in an appropriate head fixation frame to immobilize the patient's head and select an appropriate imaging coil(s) to achieve desired image quality and provide access to the procedure site.
   Caution: The patient's head must remain immobile throughout the procedure.
4. Install CleanPoint Neuro MR Neuro Procedure Drape following the Instructions for Use (IFU).
5. Determine and mark the location for burr-hole following the procedure's plan.
6. If identifying points on the scalp with an MR Fiducial is desired, follow the SMARTFrame MR Fiducial IFU.

Note: If using the Skull Mount Base, then skip Section C (Scalp Mount Base Mounting); if using the Scalp Mount Base, skip Section B (Skull Mount Base Mounting).

B. Mounting the Skull Mount Base and SMARTFrame XG Tower

1. Position the Centering Tool in the burr hole (not for burr holes smaller than 14 mm). If the burr hole is smaller than 14mm, the Centering Tool is not used.
2. Position the Base over the Centering Tool or visually center the Base over the burr hole with the single yellow fiducial marker in the up position. **See Figure 3**.
3. Using the supplied screw-driver, mount the Base with the three (3) pre-mounted self-tapping screws to the skull.
   Note: In the event a replacement screw is required for securing the Base, additional Skull Mount Screws (3) can be used.
   Note: A second set of screw-mounting holes are located in the Base adjacent to the preloaded screw holes.
   Caution: Only CleanPoint Neuro provided screws should be used for securing the Base.
   Caution: Check that the Base is secure and does not move. Confirm by feeling and observing for any movement while attempting to impart a rocking motion to the Base with the hand.

Figure 3: Base Mounting Orientation

4. Remove the Centering Tool if used.
5. Repeat the procedure for a second Base, if required for a bi-lateral procedure.
6. Once the Base(s) are attached to the skull, the SMARTFrame XG Tower is ready to insert the Targeting Cannula
7. Twist the Removable Cap so that the Tabs disengage from the TC Support Slots then remove the Cap from the TC Support.
8. Insert the Targeting Cannula into the TC Support so that the tabs on the Targeting Cannula Fit into the long vertical slot on the TC Support. Then twist the Targeting Cannula so the tabs engage the slots to lock it into position.
9. Reattach the Removable Cap by aligning the Cap's tabs with the slots in the TC Support, pressing down on the cap, and then twisting to lock the tabs into the horizontal slots.
10. Once the Targeting Cannula and Removable Cap are locked in place, the SmartFrame XG tower is ready to be mounted.
11. Orient the Tower, relative to the Base, by placing the thumb wheels of the Tower toward the two fiducial marker side of the Base. **See Figure 4**. Be sure that each of the four thumb wheels is near the center of their ranges by looking at the range marker associated with each wheel.

Figure 4

The adjustments can be made by directly turning the thumb wheels or by using the CleanPoint Neuro Thumb Wheel Extension Set. The Thumb Wheel Extension Set is an approximately 60 cm long mechanism that can be attached to the SMARTFrame XG and utilized to rotate the thumb wheels while the patient is inside of the MR scanner bore.

III. General Warnings and Precautions

- The device is intended for single-use-only and is provided sterile. Do not re-sterilize.
- Structures greater than 125 mm from the entry point should not be targeted, as placement accuracy beyond 125 mm has not been validated.
- Do not use the CleanPoint System with instruments longer than 30 cm as the accuracy of the system has not been verified with instruments greater than this length.
- Do not attach the Scalp Mount Base or Skull Mount Base Assembly to damaged or diseased bone. Only attach to stable bone to ensure rigid platform.
- Before using the System on patients under the age of 16 years, measure the skull thickness on a CT scan to ensure that the system can be secured safely onto the skull.
- When used with pediatric patients with open cranial sutures, take precautions to avoid placement that may result in placement of a screw into a cranial suture.
- Verify scanner is within calibration prior to scanning.
- Do not use a broken CleanPoint Neuro Stylet or Lancet.
- All tools and ancillary equipment and devices must be MR compatible when performing scanning. When labeling is unclear, assume the device is not compatible. Always follow the manufacturer's instructions.
- Prior to or after opening the SMARTFrame XG package, verify there is no leakage (fluid) visible on the Tower, or packaging. Do not use any device if leakage is identified.
- There are no known and reliable means of cleaning, disinfecting, repairing, and sterilizing these devices that returns them to original specifications and renders them safe and effective for reuse.
- Inspect the SMARTFrame XG package, verify there are no bubbles in the fluid filled sphere at the distal end of the Targeting Cannula. Do not use any device if such bubbles are identified.
- It is recommended that additional sterile product be available for use.
- The planned trajectory must allow for a 30 cm long device to be placed into the top of the assembled SMARTFrame XG without interfering with the bore of the MR Scanner.
- This device is to be used only by persons trained by CleanPoint Neuro personnel.
- When performing a burr hole procedure, A 14 mm burr hole is required for the CleanPoint Neuro SMARTFrame System for optimum range of motion for trajectory calculation. Reduction in burr hole diameter will prevent the use of the Centering Tool, and could interfere with the range of motion during alignment of the Tower.
- Do not place the Scalp or Skull Mount Base Assembly bone attachment screws in the cranial suture area.
- The compatibility of neurological instruments and devices should be evaluated before use with the CleanPoint Neuro SMARTFrame XG System.
- Never advance the CleanPoint Neuro Peel-Away Sheath into the brain without the supporting CleanPoint Neuro Stylet.
- Do not advance a device through the Targeting Cannula or Peel-Away Sheath that is not resistant to compression and that may change in length with insertion. This may prevent accurate placement relative to the desired target.
- Devices that are inserted through the Targeting Cannula (without the Peel-Away Sheath or one of the Device Guides) must be held from the point of insertion. Because the SMARTFrame XG until the device contacts the brain to prevent the device from advancing uncontrollably and possibly causing injury to the patient.
- Do not apply more than 0.5 lbf to the device or any component while using the SMARTFrame XG System. Examples are force against the SMARTFrame XG when inserting a device, force to insert the Stylet or Lancet into the Peel-Away Sheath.
- Orient the SMARTFrame on the patient's skull in such a manner as to prevent interference of the Thumb Wheel Extension Set with the bore of the scanner.
- Use caution when rotating the screw knob over the patient.
- When used in an IMRIS suite, confirm that the Thumb Wheel Extension Sets have clearance and that the Head Coil cable is clear so that the IMRIS scanner can move the table without damaging the Head Coil cable or breaching the sterile field created by the Bone and Patient drapes.
- Use only a Power Driver with an adjustable speed setting to secure the SmartFrame Base Bone Screws, use low speed settings to avoid breaking the Bone Screws.
- Any serious incident that has occurred in relation to the device shall be reported to the manufacturer and appropriate Competent Authority of the Member State in which the incident occurred.

Note: Safe disposal of the device: The device shall be treated as biohazardous materials and shall be disposed of accordingly per hospital policy.

General Precautions

- Handle all components using standard hospital sterile practices.
- Do not bend or kink the CleanPoint Neuro Peel-Away Sheath.
- Handle the CleanPoint Neuro Stylet and Lancet carefully to avoid breaking.
- Minimize any forces applied directly to the SMARTFrame.
- The following disposable components are MR Conditional: the SmartGrid, the Skull Mount Base, the Scalp Mount Base, the SMARTFrame XG, and the SMARTFrame Thumb Wheel Extension Set.

<u>1.5T & 3T Environment Compatibility:</u>

Non-clinical testing has demonstrated the CleanPoint System is MR Conditional. It can be scanned safely under the following conditions:

Static magnetic field of 1.5 or 3 Tesla

Spatial gradient field of 5000 Gauss/cm

Maximum whole body averaged specific absorption rate (SAR) of 2.0 W/kg for 15 minutes of scanning.

12. Mount the Tower onto the Base by first loosening then grasping the Tower Mounting Screws. Grasp the Tower by the top rectangular gear housing. Align each screw with the mating counterbore on the Base. **See Figure 5a**. Slide the Tower into place and ensure screws seat into the mounting holes on the Base.
    Caution: Avoid applying pressure to the Tower Thumb Wheels while grasping the Tower. **See Figure 5b**.



Figure 5a



Figure 5b

13. Mount the Roll Lock Screw w/ washer from the SMARTFrame XG package to pre-mount in SMARTFrame XG. Screw in partially to the appropriate location on the SMARTFrame XG. **See Figure 6.** Ensure the Roll Lock Screw w/ washer is not tight. This screw will be tightened later in the procedure.



Figure 6: Roll Lock Screw w/ washer

Caution: The Roll Lock Screw w/ washer should not be tightened until final positioning is selected. If the Roll Lock Screw w/ washer is tight during roll adjustments, adjustments will be affected and may result in inappropriate alignment.

15. Confirm that the Targeting Cannula is in the forward position to begin the procedure. **See Figure 7**.

Figure 7: Targeting Cannula positioning and Tower/Base Orientation

Caution: Do not over tighten mounting screws.

C. Mounting the Scalp Mount Base

Note: The Skull Mount Base is intended for use with a maximum scalp thickness of 9 mm using the pre-loaded screws, and 11 mm using the Long Rescue Screws. Usage with thicker scalps may prevent the Scalp Mount Base from being stabilized properly.

Note: In order to use the Scalp Mount Base for scalp thicknesses from 9 to 11 mm, ensure that only Long Rescue Screws are used.

1. The Scalp Mount Base has four adjustable height support pins and three self-tapping bone screws. **See Figure 8.** The support pins have sharp tips. **See Figure 9**. They have small protective tubes covering them. Remove the tubes before proceeding.

Figure 8: Adjustable Height Support Pins and Bone Screws for the Scalp Mount Base

Figure 9: Sharp Adjustable Height Support Pins

2. In order to center the Scalp Mount Base over the desired entry point, use one of three methods:
   - Visually center the Base over the entry point
   - Use the Mini Fiducial (MR-BAS-05) to center the Base over the entry point
   - Use the Wharen Centering Guide (REF NGS-CG-01)
3. Once the Base is in position, begin securing the Bone Screws to the skull through the scalp. Using the screw driver supplied in the SMARTFrame Kit, mount the Scalp Mount Base with the three (3) pre-mounted self-tapping screws to the skull.
   Note: In the event a replacement screw is required for securing the Scalp Mount Base, additional Scalp Mount Screws (3) can be provided.
   Note: A second set of screw-mounting holes are located in the Scalp-Mount Base adjacent to the preloaded screw holes.
   Caution: Only CleanPoint Neuro-provided screws should be used for securing the Scalp-Mount Base.
4. Secure the three bone screws into the skull. While screwing in the bone screws, check the security of the Base repeatedly, and check that the Base can lift off the scalp as the bone screws are secured.
5. Once the bone screws are secure in the skull, deploy the four support pins by screwing them down. The support pins will penetrate the scalp and will stop against the skull. The further the pins are screwed down, the more the Base will rise away from the scalp.
6. Repeatedly check the security of the Base during this operation. Once the Base is secure, proceed to the next step.
   Caution: Check that the Scalp-Mount Base is secure and does not move. Confirm by feeling and observing for any movement while attempting to impart a rocking motion to the Scalp Mount Base after mounting to the skull.
7. The SMARTFrame XG is ready to be mounted to the Base. Follow instructions from Section B step 7 through step 11 for mounting the Tower to the Base.
   Note: If creating an access hole using a drill/drill bit, then the pitch-roll and X-Y adjustments must be made prior to creating the access hole. DO NOT create the access hole prior to making pitch-roll and X-Y adjustments.
   Caution: When performing the scan and alignment check, make sure no metallic devices are inserted into the SMARTFrame XG Targeting Cannula prior to scanning.

D. Attachment of the Thumb Wheel Extension Set

1. Remove the Thumb Wheel Extension Set from its sterile barrier package. **See Figure 10**.
2. Attach the distal ends (wings) of the Thumb Wheel Extension Set to the matching colored thumb wheels on the SMARTFrame XG. **See Figure 11**. You may need to rotate the Thumb Wheel Extension Set thumb wheels to properly orient the wings into the SMARTFrame thumb wheels. The wings should slide to the bottom of the thumb wheels and seat into place.

Figure 10: Thumb Wheel Extension

Figure 11: Attachment to Thumb Wheels

E. Set Trajectory

Note: A clear understanding of and training to the CleanPoint User's Guide is required to complete the following steps.
Note: If the CleanPoint Software cannot recognize the Targeting Cannula due to low fluid levels in the Targeting Cannula, replace the Targeting Cannula by following instructions from Section F step 3 through step 6.

1. Move the patient's head to the isocenter of the MR scanner and complete the appropriate scans to gain the information necessary to begin the "Navigate" portion of the procedure.
2. The thumb wheels are color coded: Pitch is Blue, Roll is Orange, X is Yellow, and Y is Green. **See Figure 12**.

Figure 12: Tower Movements

3. Using the 'Required Adjustment' information from the CleanPoint Workstation, adjust the SMARTFrame XG to the desired trajectory. The SMARTFrame XG trajectory is adjusted by turning the four thumb wheels directly on the Tower or by turning the associated thumb wheels on the Thumb Wheel Extension Set.
4. The first/initial adjustments are made with the Pitch and Roll thumb wheels which will orient the SMARTFrame XG around the same plane and entry point.
5. The Roll Lock Screw w/ washer must be tightened after the final roll adjustment is complete. **See Figure 6**. The Roll Lock Screw w/ washer must be loosened, for subsequent roll adjustments.
6. The final adjustments are made in the X or Y directions.
   Note: Adjustments in the X and Y direction will result in a change of the pivot/entry point.
   Caution: Any subsequent adjustments that include the use of the Pitch and Roll thumb wheels will require returning to the "Navigate" portion of the procedure/software.



Figure 5a



Figure 5b

Note: The Tower movements are limited to +/- 26 degrees in roll and +/- 33 degrees in pitch directions.
Note: The Tower movements are limited to +/- 2.5 mm in the X and Y directions.
Caution: Once the trajectory is established, ensure the Thumb Wheels do not move.
Caution: Care should be taken not to induce side loading of the Tower Assembly during device insertion.
The Targeting Cannula of the SMARTFrame XG is now aligned with the Target.

F. Exchanging the Cannula, Device Guides and Inserting Instruments

1. Once the trajectory is set, use the roll locking screw to secure the position of the Frame in the pitch-roll direction.
   Caution: Avoid exerting any lateral loads on the Tower during this process to avoid unintentionally shifting the Tower's trajectory.
2. If using the MR Drill Bit, the Targeting Cannula must be removed, and the appropriately sized Device Guide must be inserted into the Tower. Refer to the technical specifications section for a list of the different MR Drill Bits and the appropriately sized Device Guides for each.
3. Twist the Removable Cap so that the Tabs disengage from the TC Support Slots. **See Figure 13**. Then, pull the Cap away from the TC Support.



Figure 13: Removing the Targeting Cannula and TC Cap

4. Repeat the procedure to remove the Targeting Cannula.
5. Insert the desired Device Guide into the TC Support so that the tabs on the Device Guide Fit into the long vertical slot on the TC Support. Then twist the Device Guide so the tabs engage the slots to lock it in position. **See Figure 14**.



Figure 14: Inserting a Device Guide

6. Attach the Removable Cap by aligning the Cap's tabs with the slots in the TC Support, pressing down on the cap, and then twisting to lock the tabs into the horizontal slots. **See Figure 15**.



Figure 15: Reattaching the TC Cap

7. If using a SmartTip™ Drill Bit and SmartTwist™ MR Hand Drill to create the access hole, refer to the MR Hand Drill IFU.
8. Once the access hole has been created, choose the appropriately-sized Device Guide, and insert it into the TC Support as described in the steps above.
9. The Dock and Lock provided with the ATF may be used with the Removable Cap. The Dock provided with the Scalp Mount Base may be used with the Removable Cap. Make sure the Removable Cap is secured to the ATF before using the Dock. See Figure 16.
10. **If inserting the Peel-Away Sheath and Ceramic Stylet: Make sure to exchange the device guide for the Targeting Cannula prior to inserting the Peel-Away Sheath and Ceramic Stylet.**
11. The instrument may be inserted into the appropriate guide and advanced to target. During insertion, view the advancement of the instrument on the CleanPoint Workstation as appropriate. This insertion and visualization may be performed in the MRI environment.
    Note: The Targeting Cannula is MRI visible. The CleanPoint system can automatically display instrument trajectory during insertion when using the Targeting Cannula. The Device Guides are not MRI Visible. It is still possible to see the instrument insertion as a void and manually check the trajectory.

PROCEDURE OPTIONS

The remaining instructions are divided into procedural paths. Follow the instructions applicable to the device being used with the SMARTFrame.

Procedures utilizing the CleanPoint Neuro Stylet and Peel-Away Sheath:
Procedures that require a Peel-Away Sheath with Stylet to confirm position by scanning and/or to create a path to the target. See Section H.

Direct insertion procedures:
Procedures that do not need placement of the Peel-Away Sheath with Stylet. See Section I.

Caution: The compatibility of neurological instruments and devices should be evaluated before use with the CleanPoint Neuro SMARTFrame System and SMARTFrame Accessories.

G. Navigational Accuracy

The device can provide a trajectory for placement of tools to targets within the brain. The radial (X-Y) plane trajectory error is < 1.5 mm at a 95% confidence interval.
Caution: The Z-plane or depth accuracy can only be verified by the user during real-time MR intraoperative imaging during placement of the instrument.

H. Procedures Utilizing the CleanPoint Neuro Stylet and Peel-Away Sheath

The CleanPoint Neuro Peel-Away Sheath with Stylet (located in the SmartFrame Accessory Kit) is used to create a path to the target and/or scanning to confirm target acquisition.

Warning: Do not use the Accessory Kit if its packaging is damaged.
Note: The SmartFrame Accessory Kit is packaged with a double sterile barrier: a tray with a sealed Tyvek lid is placed inside a sealed mylar/Tyvek pouch. Identify the Stylet and the Lancet in the tray on the sterile field. The Stylet has a bullet-nose tip, while the Lancet has a pointed tip. Make sure the Stylet is removed first.
Note: The Lancet is not available in Europe.
Note: The 7 Fr Lancet has a protective cover on the pointed tip. This should be removed before use.

Peel-Away Sheath/Stylet Preparation and Insertion

1. Remove the Dock and Device Lock from the SMARTFrame package. **See Figure 16.**



Figure 16: Dock (Left) and Device Lock (Right)

2. Remove a Peel-Away Sheath, the Stylet, and the Depth Stop from the Accessories package. Confirm that the Stylet has a bull nose tip.
   Note: The distal end of the Stylet has a bull nose tip and the proximal end of the Stylet is desired with a blue marking.
   Caution: Only CleanPoint Neuro-provided screws should be used for securing the Scalp-Mount Base.
3. Mark the target's depth on the Peel-Away Sheath by the Ruler and Marking Pen with the depth value from the CleanPoint Workstation.
4. Position the Device Lock on the depth mark on the Stylet and tighten the white thumb screw. The inserted depth of the Stylet is defined by the proximal side face of the Device Lock to the distal tip of the Stylet. Confirm the length using the Ruler. **See Figure 17**.
5. Optional: Position a Depth Stop on the Stylet; the inserted depth of the Stylet is defined by the distal side face of the Depth Stop to the distal tip of the Stylet. Slide the Stylet into Device Lock until Depth Stop rests on top of Device Lock. Tighten the white thumb screw on the Depth Stop. Confirm the length using the Ruler.
   See Figure 18.
   Caution: Do not over tighten the red thumb screw on the Depth Stop or the white thumbscrew on the Device Lock to avoid damaging or breaking the Stylet.
   Warning: Do not use a broken CleanPoint Neuro Stylet.



Figure 17: Stylet and Device Lock



Figure 18: Stylet and Depth Stop

6. A Lancet has been provided as an alternate method to create an insertion point in the dura and/or pia. If using the Lancet, proceed to step 7. If not using the Lancet, proceed to step 14.
7. Remove the Lancet from the Accessory package.
   Caution: The distal end of the Lancet has a pointed tip and the blunt proximal end is denoted with a green marking. Handle the Lancet near the proximal end. Avoid contacting the distal end.
8. Place a depth stop on the Lancet such that the distance from the distal point of the Lancet to the depth stop is approximately 1 inch greater than the distance from the inside of the dura or pia to the top of the ATF tower.
9. Remove one of the Peel-Away Sheaths from the Accessory Kit.
10. Separate the hub and peel away approximately 4 inches of the Sheath.
11. Insert the Lancet into the Peel-Away Sheath until the pointed end protrudes approximately one (1) to eight (8) millimeters. A slight resistance should be felt. If the Depth Stop interferes with the Sheath before the Lancet can be fully inserted, withdraw the Lancet and move the Depth Stop further away.
12. By holding the exposed proximal end of the Lancet, insert the Lancet through the Targeting Cannula and through the burr hole until it contacts the dura or pia. Gently push on the Lancet until the dura and/or pia is pierced.
13. After piercing the dura and/or pia, withdraw the Lancet-Sheath Assembly from the Targeting Cannula.
14. Set aside the measured Stylet. Remove a Peel-Away Sheath from the Accessory Kit package and the hub and peel away approximately one (1) inch of the Sheath.
15. Insert the peeled Sheath sides into the grooves of the Dock. **See Figure 19.**

Figure 19: Dock and Peel-Away Sheath

16. Insert the Stylet into the Sheath. The distal end of the Stylet should protrude between one (1) and five (5) mm from the end of the Sheath. If it is not protruding, pull on both ends of the hub, peel the Sheath until the distal end of the Stylet protrudes between one (1) and five (5) mm. A slight resistance should be felt.
   Warning: Verify that the Stylet is protruding from the Peel-Away Sheath prior to insertion.
17. Insert the Stylet into Dock until Device Lock mates and snap locks to Dock, making sure to orient the Device Lock such that the white thumb screw opposes the backboard extension piece of the dock. **See Figure 20.**
   Note: While peeling the Sheath to expose the Stylet tip, the force should be steady and the peel smooth.
   Caution: Do not over tighten the thumb screw on Device Lock or Depth Stop to avoid damaging the Stylet.

Figure 20: Stylet Inserted into Peel-Away Sheath

18. While the patient is in the scanner, insert the tip of the Stylet Assembly into the proximal end of the Targeting Cannula.
19. During insertion, view the advancement of the Stylet Assembly on the CleanPoint Workstation as appropriate. This insertion and visualization may be performed in 1/3 increments. **See Figure 20 for Stylet Assembly inserted into SMARTFrame XG.**
20. As insertion approaches the full measured target depth, orient the Dock such that the white line thumb screw of the Dock match up with the white lines of the flat aspects of the Device Guide Cap. **See Figure 21 for Stylet Assembly inserted into SMARTFrame XG.**
   Note: To facilitate easier attachment to the Cap, it may be necessary to pinch the center of the Lock and Dock Assembly to flare out the Dock elements with white paint. **See Figure 27.**
   The Peel-Away Sheath and Stylet Assembly is inserted to full target depth when it cannot be advanced further and fits securely over the Cap of the Device Guide.
21. Use the information from the CleanPoint Workstation to confirm the acceptability of the trajectory.

Figure 21: SMARTFrame with Stylet Assembly inserted and snap locked into place.

Warning: Do not adjust SMARTFrame XG while Stylet Assembly is inserted. If the trajectory needs to be modified, completely remove the Stylet Assembly prior to adjusting the SMARTFrame XG.
Caution: Do not over tighten thumb screws on Device Lock or Depth Stop to avoid damaging the Stylet.
Caution: Do not disengage the Peel-Away Sheath for insertion shaft deployment and go to Section I.

Device Insertion through Peel-Away Sheath with 17 GA (.057") inner diameter.

1. **Caution:** If device to be inserted is not to be imaged, position patient's head outside the scanner at the head end of the scanner.
2. If the Stylet Assembly was used previously, remove all the Stylet Assembly components except the Peel-Away Sheath, Device Lock, Stylet, and Depth Stop (if used) from SMARTFrame and separate these components from one another.
3. If necessary, select the appropriate Guide Tube (15 GA, 16 GA and 18 GA devices only) from the **SMARTFrame Guide Tubes** Kit.
   3.1 Insert the appropriate size Guide Tube into the Targeting Cannula as far as possible.
   3.2 Insert and snap lock the Dock in place. **See Figure 26.**

Figure 25: Assembly before Insertion

4. Insert the device into the top of the Device Lock.
5. Set the inserted depth on the device from the distal end of the device to the top of the Device Lock using the Ruler. Lock the device to the Device Lock with the white thumb screw. Verify the measured inserted depth. Alternately, the bottom of the Depth Stop can be located at the proximal end of the device and locked with the white thumb screw prior to inserting the device into the Device Lock. **See Figures 17 and 18** for similar placement of the Depth Stop or Device Lock onto Stylet.
   Caution: Do not over tighten the thumb screw which could damage the device.

Insertion

1. Insert the device into the Dock through the Targeting Cannula or Device Guide until the Device Lock snaps and locks onto the Dock.
   Caution: Do not advance a device through the Targeting Cannula or Device Guide that is not resistant to compression and that may change in length with insertion. This may prevent accurate placement relative to the desired target.
2. If appropriate, retract Targeting Cannula or Device Guide and secure device based on manufacturer's recommendations.
3. Perform the procedure as intended.
4. If appropriate, retract Targeting Cannula or Device Guide to the middle TC locking position and secure device based on manufacturer's recommendations.
5. Perform the procedure as intended.

Complete the Procedure

If not already complete, complete the procedure per the device manufacturer's IFU and standard surgical practices.

I. Direct Insertion Procedures

Note: This section covers preparation and direct insertion of devices that are 1.24 mm to 2.34 mm

Preparation and Insertion

Note: SMARTFrame Guide Tubes are used for providing compatibility with various diameter devices. See the chart below for the Guide Tubes required for the particular diameter device being used. Guide Tubes are color coded for identification.
Note: The Standard Device Lock is provided in the MR Tray with the SmartFrame XG. The 5 Fr and 7 Fr Device Locks are provided in the Tray with the SmartFrame XG 5 Fr and SmartFrame XG 7 Fr, respectively.

Device Diameters		Guide Tube	Device Lock
.050"	1.24 mm	18 GA	.052" Guide Tube (blue)	Standard
.058"	1.47 mm	17 GA	.060" Guide Tube (black)	Standard
.061"	ClearPoint Stylet		.064" Guide Tube (green)	Standard
.070"	ClearPoint 5 Fr Stylet		.074" Guide Tube (white)	5 Fr
.065"	1.65 mm	16 GA	.066" Guide Tube (orange)	Standard
.072"	1.80 mm	15 GA	.074" Guide Tube (white)	Large (yellow)
.083"	2.11 mm	14 GA	None required	Large (yellow)
.092"	2.34 mm	N/A	None required	Large (yellow)
.098

Cadre de trajectoire guidée pour IRM SMARTFrame XG

MODE D'EMPLOI

Table des matières

I. Utilisation prévue
II. Description du dispositif
III. Généralités, avertissements et précautions
IV. Mode d'emploi
A. Préparation
B. Montage de la base de fixation au crâne et de la tour SMARTFrame XG
C. Montage de la base de fixation sur cuir chevelu
D. Fixation du dispositif d'extension de molettes
E. Définition de la trajectoire
F. Changement de la canule et des guides du dispositif et insertion des instruments
G. Précision de la navigation
H. Procédure utilisant le stylet ClearPoint Neuro et la gaine pelable Peel-Away
I. Procédures d'insertion directe
J. Retrait du système
K. Entretien et caractéristiques techniques
Utilisation prévue
Le système ClearPoint est destiné à fournir un guidage stéréotaxique pour le placement et l'utilisation d'instruments ou de dispositifs lors de la planification et de l'exécution de procédures neurologiques dans l'environnement IRM et en conjonction avec l'imagerie par RM. Le système ClearPoint est destiné à faire partie intégrante des procédures qui utilisent traditionnellement la stéréotaxie neurologique. Ces procédures comprennent de biopsies, la chirurgie ablative et l'insertion de thérapies. Le système est uniquement destiné à être utilisé avec des scanners IRM de 1,5 et 3,0 Tesla.
Avertissement : Le système Neuro ClearPoint de la classe de risque IIb est utilisé pour guider une électrode de stimulation cérébrale profonde (SCP) dans une cible cérébrale spécifique telle que le noyau sous-thalamique. La mise en place définitive des électrodes de SCP nécessite des enregistrements physiologiques pour vérifier qu'elles sont situées dans la cible. Même si elle est considérée et qu'elles fonctionnent comme prévu, le système ClearPoint de ClearPoint Neuro ne fournit pas de bénéfice clinique direct. Le bénéfice clinique pour l'enregistrement physiologique de l'activité cérébrale. La sécurité et l'efficacité de l'utilisation du système Neuro ClearPoint de ClearPoint SEUL pour la mise en place finale des électrodes de SCP n'ont pas été établies.
Avertissement : Ce dispositif est destiné à un usage unique. Le contenu de l'emballage non ouvert et non endommagé est stérile. Ne pas restériliser.
Remarque : Pour une description complète de la gamme, se référer au Guide de l'utilisateur du système ClearPoint.

II. Description du dispositif

Contenu de l'emballage (un exemplaire des éléments suivants) :

NGS-SF-02-11-E	Cadre de trajectoire guidée pour IRM SMARTFrame XG - Europe Cadre stéréotaxique, base de fixation crânienne, anneau de centrage, vis de centrage, verrou pour dispositif d'extension, guide de trajectoire, tournevis, vis anti-rouleis avec rondelle, vis de rechange (3)	NGS-SF-02-11-S-E	Cadre de trajectoire guidée pour IRM, 5 Fr SMARTFrame SF - Europe Cadre stéréotaxique, anneau de centrage, socle, verrou pour dispositif d'extension, guide de trajectoire, tournevis, vis anti-rouleis avec rondelle

Dispositifs associés :

NGS-TE-01	Dispositif SMARTFrame d'extension de molettes. Extrémité hexagonale	NGS-PD-02-L-E	Drap pour intervention neuro sous RM, conique – Long Drape d'intervention neuro sous RM, conique, avec fenêtre, manipule, cache-boule de suivi
NGS-AK-01-11-4-E	Kit d'accessoires SMARTFrame — Europe Stylet 4Fr, gaine pelable Peel-Away 4Fr DI (2), règle, boîte de protection VIP	NGS-PD-03-L-E	Drap pour intervention neuro sous RM, conique avec extension – Long Drap d'intervention neuro sous RM, conique avec extension, style marquage, cache-boule de suivi
NGS-AK-01-11-5-E	Kit d'accessoires SMARTFrame — 5 Fr - Europe Stylet 5 Fr, gaine pelable Peel-Away 4Fr DI (2), règle, boîte de protection VIP	NGS-PD-04-E	Drap d'allège pour IRM neuro avec extension Drap d'allège du scanner à RM neuro avec extension
NGS-AK-01-11-7-E	Kit d'accessoires SMARTFrame — 7 Fr - Europe Stylet 7 Fr, gaine pelable Peel-Away 7 Fr DI (2), règle, boîte de protection (2)	NGS-PD-05-E	Drap de patient pour RM neuro Drap pour patient pour RM neuro, style marque, cache-boule de suivi, cache-câble
NGS-SG-01-11	Guide de localisation IRM SMARTGrid Grille de marquage et outil de marquage	NGS-MI-01-E	Guides de diagnostic interchangeables XG SMARTFrame Guide pour dispositif, 3,4 mm, Guide pour dispositif, 14 GA
NGS-SM-01-E	Base de fixation sur le cuir chevelu – Europe Base de fixation sur le cuir chevelu et outil de centrage, vis de rechange (3)	NGS-XG-03-E	Base de fixation sur le cuir chevelu Guide du dispositif de 2,5 mm
NGS-XG-02-E	Guide du dispositif interchangeable SMARTFrame XG, 4,5 mm Guide du dispositif de 4,5 mm	NGS-TC-01	Canule de clôture SMARTFrame XG Canule de clôture
NGS-GT-01	Tube guide SMARTFrame Tube de guidage 15 GA, tube de guidage 18 GA et tube de guidage 22 GA		

REMARQUE : En cas d'utilisation de dispositifs autres que ceux fournis par ClearPoint Neuro, vérifier l'ajustement du dispositif dans le tube de guidage, le guide du dispositif ou la canule. Si nécessaire, retirer les recommandations de fabrication et remplacer par le dispositif avec l'IRM avant l'utilisation.

La tour SMARTFrame XG (Echangeable Guide) est conçue pour être utilisée avec la base de fixation sur cuir chevelu ou la base standard SMARTFrame, qui sont toutes deux entièrement en plastique, à l'exception des vis osseuses et des broches de fixation. La tour **voir la figure 1** se fixe à la base. La tour, également entièrement en plastique, est conçue pour prendre des réglages grossiers/fins multidirectionnels de la cible et de l'angle de la trajectoire. Un système de verrouillage de la tour est également fourni. Une sphère étoilée remplie de fluide et une colonne presonnée remplie de fluide qui sont toutes deux visibles à l'IRM. La canule de clôture possède également une lumière centrale à travers laquelle il est possible de placer des instruments pour une gaine pelable Peel-Away en stylet ou d'autres dispositifs appropriés. Le tube, longitudinal est fixé à la base de la tour de fixation sur le cuir chevelu, permet des réglages dans les directions du roulis, du tangage, de l'axe Y et de l'axe Y en tournant les molettes appropriées. La tour XG est dotée d'un capuchon qui peut être retiré pour faciliter le remplacement de la canule de clôture par des guides de dispositifs interchangeables SMARTFrame XG pour l'insertion de cathéters, d'instruments ou de différentes tailles après l'obtention et le verrouillage de la trajectoire vers la cible. **Voir la Figure 2.**
Les réglages peuvent être effectués directement les molettes ou à distance à l'aide du dispositif d'extension de molettes ClearPoint Neuro. Le dispositif d'extension de molettes est un mécanisme d'environ 60 cm de long qui peut être fixé au SmartFrame XG et utilisé pour faire tourner les molettes pendant que le patient est à l'intérieur de l'alésage du scanner RM.

III. Généralités, avertissements et précautions

- Le dispositif est destiné à un usage unique et est fourni stérile. Ne pas restériliser.
- **Avertissement :** Les structures situées à plus de 125 mm du point d'entrée ne doivent pas être ciblées, car la précision du positionnement au-delà de 125 mm n'a pas été vérifiée.
- **Avertissement :** Ne pas utiliser le système ClearPoint avec des instruments de plus de 30 cm de long, car la précision du système n'a pas été vérifiée avec des instruments de cette longueur.
- **Avertissement :** Ne pas faire la base de fixation au cuir chevelu ou au crâne sur un os endommagé ou malade. Ne la fixer que sur un os stable pour garantir la solidité de la plateforme.
- **Avertissement :** Avant d'utiliser le système sur des patients de moins de 16 ans, mesurer l'épaisseur du crâne au sommet pour s'assurer que le système peut être fixé en toute sécurité sur le crâne.
- **Avertissement :** Lorsqu'il est utilisé sur des patients pédiatriques ayant des sutures crâniennes ouvertes, prendre des précautions pour éviter tout positionnement qui pourrait entraîner l'insertion d'une vis dans une suture crânienne.
- **Avertissement :** Vérifier que le scanner n'est bien éteinte avant de procéder au laçage.
- **Avertissement :** Ne pas utiliser le système ClearPoint avec des scanners IRM non cliniques.
- **Avertissement :** Il existe aux environs de faible de nettoyeur, désinfecter, réparer et stériliser ces dispositifs de manière à les ramener à leurs spécifications d'origine et à les rendre sûrs et efficaces pour leur réutilisation.
- **Attention :** Avant tout usage, ouvrir l'emballage du SMARTFrame XG, vérifier qu'il n'y a pas de bulles dans la solution remplie de fluide à l'intérieur de la canule de clôture. Ne pas utiliser un dispositif s'il se faites bulles sont constatées.
- **Attention :** Ne pas réutiliser ou disposer d'un produit stérile usagé.
- **Attention :** La trajectoire prévue doit permettre de placer un dispositif de 30 cm de long dans la partie supérieure du SMARTFrame XG assemblé sans interférer avec l'alésage de la machine IRM.
- **Attention :** Ce dispositif ne doit être utilisé que par des médecins formés par le personnel de ClearPoint Neuro.
- **Attention :** Les données d'imagerie pour intervention de trajectoire ne doivent pas être utilisées à des fins de diagnostic.
- **Attention :** Vérifier à plusieurs reprises la sécurité de la base pendant cette opération. Une fois que la base est sécurisée, passer à l'étape suivante.
- **Remarque :** Vérifier que la base est bien fixée et ne bouge pas. Vérifier en resentant et en observant tout mouvement tout en essayant de donner un mouvement de bascule à la base de fixation au cuir chevelu après la fixation sur le crâne.
- **Remarque :** Le SMARTFrame XG est prêt à être monté sur la base. Suivre les instructions de la section B, étapes 7 à 11. pour monter la tour à la base.
- **Remarque :** En cas de rotation d'un orifice d'accès à l'aide d'une perceuse, le diamètre de l'ouverture longitudinale et à l'axe X-Y doivent être effectués avant de créer l'orifice d'accès. NE PAS créer l'orifice d'accès avant d'avoir effectué les réglages de l'assiette longitudinale et de l'axe Y.
- **Attention :** Lors de la vérification du balayage et de l'alignement, s'assurer qu'aucun dispositif métallique n'est inséré dans la canule de clôture SMARTFrame XG avant le balayage.

IV. Fixation du dispositif d'extension de molettes

1. Sortir le dispositif d'extension de molettes de son emballage stérile. **Voir la Figure 10.**
2. Fixer les extrémités dotées (alettes) du dispositif d'extension de molettes de couleur correspondante sur le SMARTFrame XG. **Voir la Figure 11.** Il sera peut-être nécessaire de faire pivoter les molettes du dispositif d'extension pour orienter correctement les alettes dans les molettes du SMARTFrame. Les alettes doivent glisser jusqu'au fond des molettes et s'y loger.

E. Définition de la trajectoire

Remarque : Une bonne compréhension du Guide de l'utilisateur ClearPoint et une formation à celui-ci sont nécessaires pour effectuer les étapes suivantes.
Remarque : Si le logiciel ClearPoint ne reconnaît pas la cannule de clôture en raison d'un niveau de liquide trop bas dans celle-ci, replacer la cannule de clôture en suivant les instructions des étapes 3 à 6 de la section F.

1. Déplacez tôte ito patient jusqu'à l'ouverture de l'appareil d'IRM et effectuer les balayages appropriés pour obtenir les informations nécessaires pour commencer la partie « Navigation » de l'intervention.
2. Les molettes sont codées par couleur : le tangage est bleu, le roulis est orange, X est jaune et Y est vert. **Voir la Figure 12.**
3. À l'aide des informations relatives à l'ajustement nécessaire fournies par le Guide de l'utilisateur, régler le SMARTFrame XG sur la trajectoire souhaitée. La trajectoire du SMARTFrame XG est ajustée en tournant les quatre molettes directement sur la tour ou sur les molettes associées sur le dispositif d'extension des molettes.
4. Les premiers réglages s'effectuent avec les molettes Tangage et Roulis qui orientent le SMARTFrame XG autour du même point de pivot et d'entrée.
5. La vis anti-rouleis avec rondelle doit être serrée une fois le réglage final du roulis terminé. Voir la Figure 3. La vis anti-rouleis avec rondelle doit être desserrée pour les réglages suivants de la trajectoire.
6. Les ajustements finaux sont effectués dans les directions X ou Y.
   Remarque : Les ajustements dans la direction X et Y entraînent un changement du point de pivot d'entrée.
   Attention : Tout réglage ultérieur impliquant l'utilisation des molettes de tangage et de roulis nécessitera de revenir à la partie « Navigation » de la procédure du logiciel.
   Remarque : Les mouvements de la tour sont limités à **+/- 20 degrés** dans toutes les directions.
   Remarque : Lorsque le réglage est terminé, le SMARTFrame XG est verrouillé en position. Vérifier à plusieurs reprises que le dispositif n'est pas endommagé ou déformé.
   Remarque : Tirer sur les poignées de la gaine pelable Peel-Away en ligne droite pendant l'extraction; la faire tourner uniquement dans le sens horaire pour éviter de déplacer la cible. Ne pas faire passer dans la canule de clôture ou la gaine pelable Peel-Away un dispositif qui ne résiste pas à la compression et dont la longueur peut varier lors de l'insertion. Cela peut empêcher un positionnement précis par rapport à la cible souhaitée.
   Attention : Ne pas faire passer dans la canule de clôture ou la gaine pelable Peel-Away un dispositif qui ne résiste pas à la compression et dont la longueur peut varier lors de l'insertion. Cela peut empêcher un positionnement précis par rapport à la cible souhaitée.
   Attention : Ne pas faire passer de cathéter à travers le SMARTFrame XG pour le retirer du vermouillage du dispositif.
7. Serrer la vis à ailettes blanche de vermouillage sur le dispositif.
   Attention : Ne pas serrer excessivement la vis à ailettes blanche, car le dispositif pourrait se rompre.
8. Le cas échéant, retirer la gaine pelable Peel-Away en tirant simultanément sur les deux extrémités du moyeu rouge fendu jusqu'à ce que la gaine soit entièrement retirée du guide du dispositif.

F. Changement de la canule, des guides du dispositif de perçage et des instruments d'insertion.

1. Une fois la base de fixation au cuir chevelu fixée, retirer les anti-rouleis pour faire tourner la tour dans la zone de non-tangage-roulis.
   Attention : Éviter d'exercer des poussées latérales sur la tour pendant cette opération afin de ne pas modifier involontairement sa trajectoire.
2. En cas d'utilisation d'un dispositif de guidage, retirer le guide du dispositif de perçage de la canule de clôture. Le guide du dispositif de perçage est conçu pour s'ouvrir facilement lorsqu'il est tiré vers le haut. Saisir le guide du dispositif de perçage entre le pouce et l'index et tirer vers le haut. Le guide du dispositif de perçage est conçu pour s'ouvrir facilement lorsqu'il est tiré vers le haut. Saisir le guide du dispositif de perçage entre le pouce et l'index et tirer vers le haut.
   Remarque : Si le guide du dispositif de perçage ne s'ouvre pas facilement, il peut être nécessaire de le faire pivoter légèrement dans le sens horaire ou antihoraire pour le libérer.
3. Retirer la canule de clôture SMARTFrame XG en maintenant stable avec le doigt.
   Attention : Ne pas faire passer dans la canule de clôture ou la gaine pelable Peel-Away un dispositif qui ne résiste pas à la compression et dont la longueur peut varier lors de l'insertion. Cela peut empêcher un positionnement précis par rapport à la cible souhaitée.
   Attention : Ne pas faire passer de cathéter à travers le SMARTFrame XG pour le retirer du vermouillage du dispositif.
4. Le cas échéant, retirer le guide pelable Peel-Away en tirant simultanément sur les deux extrémités du moyeu rouge fendu jusqu'à ce que la gaine soit entièrement retirée du guide du dispositif.
5. Les ajustements finaux sont effectués dans les directions X ou Y.
   Remarque : Les ajustements dans la direction X et Y entraînent un changement du point de pivot d'entrée.
   Attention : Tout réglage ultérieur impliquant l'utilisation des molettes de tangage et de roulis nécessitera de revenir à la partie « Navigation » de la procédure du logiciel.
   Remarque : Les mouvements de la tour sont limités à **+/- 20 degrés** dans toutes les directions.
   Remarque : Lorsque le réglage est terminé, le SMARTFrame XG est verrouillé en position. Vérifier à plusieurs reprises que le dispositif n'est pas endommagé ou déformé.
6. Les ajustements finaux sont effectués dans les directions X ou Y.
   Remarque : Les ajustements dans la direction X et Y entraînent un changement du point de pivot d'entrée.
   Attention : Tout réglage ultérieur impliquant l'utilisation des molettes de tangage et de roulis nécessitera de revenir à la partie « Navigation » de la procédure du logiciel.
7. Les ajustements finaux sont effectués dans les directions X ou Y.
   Remarque : Les ajustements dans la direction X et Y entraînent un changement du point de pivot d'entrée.
   Attention : Tout réglage ultérieur impliquant l'utilisation des molettes de tangage et de roulis nécessitera de revenir à la partie « Navigation » de la procédure du logiciel.
8. Les ajustements finaux sont effectués dans les directions X ou Y.
   Remarque : Les ajustements dans la direction X et Y entraînent un changement du point de pivot d'entrée.
   Attention : Tout réglage ultérieur impliquant l'utilisation des molettes de tangage et de roulis nécessitera de revenir à la partie « Navigation » de la procédure du logiciel.

G. Précision de la navigation

Le dispositif permet une trajectoire pour le positionnement d'outils vers des cibles dans le cerveau. Lerreur de trajectoire dans le plan radial (R-XY) est < 1,5 mm avec un intervalle de confiance de 95 %.
Remarque : Une distance de 2 ou de la profondeur ne peut être vérifiée par l'utilisateur que lors de l'imagerie peropératoire par RM en temps réel pendant la mise en place de l'instrument.

H. Procédure utilisant le stylet ClearPoint Neuro et la gaine pelable Peel-Away :

Les paragraphes suivants décrivent les procédures au cours lesquelles la gaine pelable avec stylet (située dans le kit d'accessoires SmartFrame) est utilisée pour créer un chemin vers la cible. **Voir la section H.**
Avertissement : Ne pas utiliser le kit d'accessoires si son emballage est endommagé.
Remarque : Examiner le stylet et la gaine pelable avec stylet avant de les insérer dans le tube guide. Le stylet doit être fermement ancré dans la gaine, mais il doit pouvoir être utilisé avec le stylet. Vérifier le stylet et la lancette dans le plateau avant de les retirer. Le stylet a un embout arrondi en obus, tandis que la lancette a un embout pointu. Veiller à retirer le stylet en premier. REMARQUE : La lancette est destinée à être utilisée une seule fois.
Remarque : Lextrémité pointue de lancette de 5 Fr / 7 Fr comporte un capuchon de protection qui doit être enlevé avant utilisation.
Préparation et insertion de la gaine pelable Peel-Away® stylet

1. Retirer le socle et le vermouillage du dispositif de l'emballage du SMARTFrame. **Voir la figure 16.**
2. Retirer la gaine pelable avec stylet de l'emballage du dispositif de profondeur de l'emballage des accessoires. Vérifier que le stylet a un embout arrondi en obus.
   Remarque : Lextrémité distale du stylet a une pointe arrondie en forme d'obus et l'extrémité proximale du stylet est indiquée par un marqueur bleu.
   Remarque : Lextrémité distale du stylet ne sert qu'à veiller à la pénétration sans à-coups de la gaine pelable. Le stylet ne doit pas dépasser la tissu intact pour le dispositif final. Soustraire ce « décalage » de distance de la valeur de profondeur fournie par le poste de travail ClearPoint.
3. Marquer la ligne médiane sur le cuir chevelu à l'aide d'un stylo. Faire glisser le tube guide du dispositif au sommet du poste de travail ClearPoint.
4. Positionner le vermouillage du dispositif sur le repère de profondeur du stylet et serrer la vis à ailettes blanche. La profondeur d'insertion du stylet est définie par la face distale de la butée de profondeur (indiquée par la flèche). Faire glisser le tube guide du dispositif jusqu'à l'extrémité de la gaine pelable avec stylet. Vérifier que le stylet a été mis en place et qu'il est bien verrouillé.
   Remarque : Si un dispositif d'extension de molettes est utilisé, il est également possible de placer le bas de la butée de profondeur à l'endroit approximatif où il doit se trouver sur l'épaisseur à l'aide de la vis à ailettes. Il est également possible de placer le bas de la butée de profondeur à l'endroit approximatif où il doit se trouver sur l'épaisseur à l'aide de la vis à ailettes. Le dispositif d'extension de molettes peut avant d'insérer l'appareil dans le vermouillage du dispositif. **Voir les figures 17 et 18** pour un positionnement similaire de la butée de profondeur ou du vermouillage du dispositif sur le stylet.
   Attention : Ne pas trop serrer sur la vis à ailettes, ce qui pourrait endommager le dispositif.

Insertion

1. Insérer le dispositif dans le socle à travers la canule de clôture ou le guide du dispositif jusqu'à ce que le vermouillage du dispositif s'enclenche et se vermouille sur le socle. Vérifier que le stylet, la gaine pelable Peel-Away et le guide du dispositif sont tous verrouillés en place. Retirer le stylet pour la la compression et donné la longueur pour varier lors de l'insertion. Cela peut empêcher un positionnement précis par rapport à la cible souhaitée.
2. Le cas échéant, retirer la canule de clôture ou le guide du dispositif jusqu'à la position centrale de vermouillage du dispositif.
3. Effectuer l'insertion comme prévu.
4. Le cas échéant, attracter la canule de clôture ou le guide du dispositif jusqu'à la position centrale de vermouillage de la CC et fixer le dispositif conformément aux recommandations du fabricant.
5. Effectuer l'insertion comme prévu.

Terminer la procédure

1. Retirer le stylet, effectuer la procédure conformément à la notice d'utilisation du fabricant du dispositif et aux pratiques chirurgicales standard.

J. Retrait du système

Remarque : Il est recommandé de procéder au retrait du système avec la tête du patient à l'extérieur de l'alésage du scanner, du côté tête du scanner.
Avertissement : Vérifier que le dispositif s'il est présent) est fixé conformément aux instructions du fabricant avant de retirer les composants du SmartFrame car le dispositif pourrait se déplacer.
Retirer le dispositif d'extension de molettes en tenant la molette appropriée sur le SMARTFrame, tout en tirant doucement sur l'extension de molette dans la direction opposée.
1. Dessserrer et retirer la butée de profondeur si elle est utilisée.
2. Desserrer et retirer la vis à ailettes blanche du vermouillage du dispositif.
3. Retirer le socle et l'ensemble de vermouillage du dispositif en appuyant sur les clips pour le séparer du SMARTFrame. **Voir la Figure 27.**
4. Faire glisser la vis à ailettes et l'ensemble de vermouillage du dispositif pour les retirer complètement.
6. Retirer la vis anti-rouleis avec sa rondelle.
7. Desserrer les vis de montage de la tour et séparer la tour de base.
8. Retirer la base du cuir chevelu en desserrant les vis osseuses en étoile.
   Attention : Éviter de serrer la base pendant son retrait, ce qui pourrait causer les vis restantes.

K. Entretoupage et caractéristiques techniques

Entreposage

- Entreposer dans un endroit frais et sec

Caractéristiques techniques

- SMARTFrame
  - **Précision du dispositif**
    Le dispositif guidera un outil rigide vers la cible cérébrale visée avec une erreur inférieure à 1,5 mm.
  - **Hauteur totale (haut du dispositif de vermouillage)** : 152,4 mm (6.00 po.)
  - **Tailles d'instruments et guides de diagnostic ou de forages appropriés**

Taille de l'instrument (mm)	Diamètre intérieur du guide (mm)	Numéro de catalogue du guide
< 2,1	N/D	N/D**
2,1 – 2,3	2,38 (Orange)	NGS-XG-01
2,35 – 2,45	2,48 (Bleu)	NGS-XG-03
2,8 – 3,2	3,25 (Noir)	NGS-XG-04
3,0 – 3,4	3,58 (Blanc)	NGS-XG-05
3,5 – 4,5	4,65 (Vert)	NGS-XG-02
5,2 – 5,4	5,56	NGS-XG-06

Pour les dispositifs dont le diamètre extérieur est inférieur ou égal à 2,1 mm, la canule de clôture peut être utilisée seule ou avec le tube de guidage approprié. **Voir la section I pour l'utilisation appropriée des tubes de guidage avec le SMARTFrame XG

- **Plages de mouvement**

Orientation	Déplacement	Déplacement pour un tour de la molette	Couleur de la molette
Roulis	± 26°	4°	Orange
Tangage	± 33°	4°	Bleu
« X »	± 2,5 mm	1 mm	Jaune
« Y »	± 2,5 mm	1 mm	Vert

Traduit de la version originale en anglais

ISTRUZIONI PER L'USO

Sommario

I. Uso previsto
II. Descrizione del dispositivo
III. Avvertenze e precauzioni generali
IV. Istruzioni per l'uso
A. Preparazione
B. Assemblaggio della base del mongoggio per il cranio e della cornetta XG
C. Assemblaggio della base del mongoggio per il cuoio capelluto
D. Fissaggio del set di estensione della rotella zigrinata
E. Impostazione della traiettoria
F. Sostituzione della cannula e delle guide del dispositivo e inserimento degli strumenti
G. Precisione della navigazione
H. Procedure che utilizzano lo stiletto e la guaina staccabile ClearPoint Neuro
I. Procedure di inserimento diretto
J. Rimozione del sistema
K. Conservazione e specifiche tecniche

I. Uso previsto

Il sistema ClearPoint è stato progettato per fornire una guida stereotassica per il posizionamento e l'utilizzo di strumenti o dispositivi durante la pianificazione e l'esecuzione di procedure neurologiche all'interno dell'ambiente di risonanza magnetica (RM) e in combinazione con l'imaging a RM. Il sistema ClearPoint è destinato a far parte integrante delle procedure che utilizzano tradizionalmente la stereotassia neurologica. Tali procedure includono biopsie e inserimento di cateteri ed elettrodi. Il sistema è destinato all'uso solo con scanner MRI da 1,0 e 1,5 Tesla.
Avvertenza: Il sistema ClearPoint Neuro, ClearPoint DA SOLO non deve essere usato per guidare un elettrodo di stimolazione cerebrale profonda (deep brain stimulation, DBS) in un target cerebrale specifico come il nucleo subtalamico. Il posizionamento finale degli elettrodi DBS richiede registrazioni fisiologiche per confermare che sono situati nel target previsto. Anche se considerato e funzionante come previsto, il sistema ClearPoint non è progettato per fornire un beneficio clinico diretto a essere utilizzato per la registrazione fisiologica dell'attività cerebrale. La sicurezza e l'efficacia dell'uso del sistema ClearPoint Neuro ClearPoint DA SOLO per il posizionamento finale degli elettrodi DBS non sono state stabilite.
Avvertenza: Il presente dispositivo è esclusivamente monouso. Il contenuto della confezione non aperta e non danneggiata è sterile. Non risterilizzare.
Nota: per una descrizione completa della gamma, fare riferimento al Manuale dell'utente del sistema ClearPoint.

II. Descrizione del dispositivo

Contenuto della confezione (uno dei seguenti):

NGS-SF-02-11-E	Telaio per la traiettoria guidata da MRI XG SMARTFrame - Europa Telaio stereotassico, base di montaggio per il cranio, anello di centraggio, dispositivo, blocco del dispositivo, vite di centraggio, chiave esagonale, tornavite, chiave a brugola per viti anti-rollio con rondella, viti di sostituzione (3)	NGS-SF-02-11-S-E	Telaio per la traiettoria guidata da MRI XG SMARTFrame, 5 Fr - Europa Telaio stereotassico, anello di centraggio, alloggiamento, blocco del dispositivo, vite di centraggio, chiave esagonale, cacciavite, vite di blocco anti-rollio con rondella, viti di sostituzione (3)

Dispositivi associati:

NGS-TE-01	Set di estensione della rotella zigrinata SMARTFrame. Centralina manuale leggera	NGS-PD-02-L-E	Telo affaloatato per procedure neurologiche RM - Lungo Telo affaloato per procedure neurologiche RM, personalità, copri-sfera
NGS-AK-01-11-4-E	Kit di accessori SMARTFrame - Europa Stilo da 4 Fr, guaina staccabile con Dr da 4 Fr (2), righello, fermo di profondità (2)	NGS-PD-03-L-E	Telo affaloatato per procedure neurologiche RM con estensione - Lungo Telo affaloato per procedure neurologiche RM con estensione, personalità, copri-sfera
NGS-AK-01-11-5-E	Kit di accessori SMARTFrame, 5 Fr - Europa Stilo da 5 Fr, guaina staccabile con Dr da 4 Fr (2), righello, fermo di profondità (2)	NGS-PD-04-E	Telo di copertura per scanner neurologico RM con estensione Telo di copertura per scanner neurologico RM con estensione
NGS-AK-01-11-7-E	Kit di accessori SMARTFrame, 7 Fr - Europa Stiletto da 7 Fr, guaina staccabile con Dt da 7 Fr (2), righello, fermo di profondità (2)	NGS-PD-05-E	Telo per paziente neurologico RM Telo per paziente neurologico RM, pannello, copri-sfera, copri-cavo
NGS-SG-01-11	Griglia di pianificazione RM SMARTGrid Griglia di localizzazione e strumento di marcatura	NGS-XG-01-E	Guide intercambiabili del dispositivo XG SMARTFrame Guida del dispositivo da 3,4 mm
NGS-SM-01-E	Base di montaggio per il cuoio capelluto - Europa Base di montaggio per il cuoio capelluto e strumento di centraggio, vite di sostituzione (3)	NGS-XG-03-E	Guide intercambiabili del dispositivo XG SMARTFrame, 14 GA Guida del dispositivo da 2,5 mm
NGS-XG-02-E	Guide intercambiabili del dispositivo XG SMARTFrame, 4,5 mm Guida del dispositivo da 4,5 mm	NGS-TC-01	Cannula di puntamento SMARTFrame XG Cannula di puntamento
NGS-GT-01	Tubi guida SMARTFrame Tubo guida da 15 GA, tubo guida da 18 GA e tubo guida da 16 GA		

Nota: se si utilizzano dispositivi diversi da quelli forniti da ClearPoint Neuro, verificare che il dispositivo si adatti al tubo guida, alla guida del dispositivo o alla guida per trapano e rimuovere alle raccomandazioni del produttore relative alla compatibilità con l'MRI prima dell'uso.

La torretta con guida intercambiabile (XG, Exchangeable Guide) SMARTFrame è progettata per l'uso con la base di montaggio per il cuoio capelluto o con la base standard SMARTFrame, entrambe completamente in plastica ad eccezione delle viti ossee e dei perni di supporto. La torretta (**vedere la figura 1**) si collega alla base. La torretta, anchessa completamente in plastica, è progettata per consentire regolazioni grossolane/fini multidirezionali del target e dell'angolo della traiettoria. È inoltre fornito un sistema di bloccaggio della torretta. La sfera di puntamento è dotata di una sfera stellare riempita di liquido e di una colonna presonnale riempita di liquido, entrambe visibili a RM. La cannula di puntamento è inoltre dotata di una luce centrale attraverso la quale è possibile posizionare strumenti per una guaina staccabile Peel-Away o altri dispositivi appropriati. Il tubo, longitudinale, è fissato alla base della torretta di fissaggio sul cuoio capelluto, consente regolazioni nella direzione del rollio, del beccheggio, dell'asse Y e dell'asse X ruotando le manopole appropriate. La torretta XG è dotata di un cappuccio che può essere rimosso per facilitare la sostituzione della cannula di puntamento con le guide per dispositivi intercambiabili SMARTFrame per l'inserimento di cateteri, strumenti o dimensioni diverse dopo aver ottenuto e bloccato la traiettoria verso il target. Le regolazioni possono essere effettuate direttamente sulle manopole o a distanza utilizzando il dispositivo di estensione delle manopole ClearPoint Neuro. Il set di estensione della rotella zigrinata ClearPoint Neuro. Il set di estensione della rotella zigrinata è un meccanismo di circa 60 cm di lunghezza che può essere fissato a SmartFrame XG e utilizzato per ruotare le manopole mentre il paziente è all'interno della galleria di scansione RM.

III. Avvertenze e precauzioni generali

- Il dispositivo è esclusivamente monouso ed è fornito sterile. Non risterilizzare.
- **Avvertenza:** non puntare strutture che si trovano a più di 125 mm dal punto di ingresso in quanto la precisione di posizionamento oltre i 125 mm non è stata convalidata.
- **Avvertenza:** non utilizzare il sistema ClearPoint con strumenti più lunghi di 30 cm, poiché la precisione del sistema non è stata verificata con strumenti di questa lunghezza.
- **Avvertenza:** non fissare il gruppo di montaggio per il cuoio capelluto o la base per il cranio su un osso danneggiato o malato. Fissare solo su un osso stabile per garantire una piattaforma solida.
- **Avvertenza:** prima di utilizzare il sistema su pazienti di età inferiore ai 16 anni, misurare lo spessore del cranio con una TAC per garantire che il sistema possa essere fissato in modo sicuro al cranio.
- **Avvertenza:** quando si utilizza su pazienti pediatrici con suture craniche aperte, adottare precauzioni per evitare qualsiasi posizionamento che potrebbe causare l'ingresso di una vite in una sutura cranica.
- **Avvertenza:** verificare che lo scanner sia tranna prima di eseguire la scansione.
- **Avvertenza:** non utilizzare il sistema ClearPoint Neuro insieme a scanner RM non clinici.
- **Avvertenza:** tutti gli strumenti e le apparecchiature e i dispositivi ausiliari contenuti durante l'esecuzione della scansione devono essere compatibili con la RM. Se l'etichetta mri = sicura, pericolosa o mri = pericolosa, non portare l'oggetto nella stanza dello scanner. Gli oggetti ferromagnetici possono essere pericolosi.
- **Avvertenza:** Lingresso della stanza dello scanner deve essere sempre sorvegliato per garantire che solo il personale addestrato e autorizzato sia presente durante la procedura. Prima di entrare nella stanza dello scanner, tutti i membri del personale devono rimuovere tutti i gioielli e gli oggetti metallici, compresi i dispositivi elettronici, come orologi da polso, carte di credito con banda magnetica e apparecchi acustici. Tutti i membri del personale devono inoltre rimuovere tutti i piercing e le protesi che possono essere influenzati dalla RM.
- **Avvertenza:** Prima di entrare nella stanza dello scanner, tutti i membri del personale devono rimuovere tutti